

# INDEX OF PARTS

Battery 9V

Battery Connector 9V (Side)

Battery Connector 9V

Capacitor .001uF 102

Capacitor .1uF 104

Capacitor .05uF 503

Capacitor .022uF 223

Capacitor .033uF 333

Capacitor .047uF 473

Capacitor 180puF 181

Capacitor Blank (Large)

Capacitor Blank (Med)

Capacitor Blank (Small)

Capacitor Cylinder .022uF 223

Capacitor Cylinder Blank

Capacitor Mustard .022uF 223

Capacitor Mustard Blank

Capacitor Orange Drop .022uF 223

Capacitor Orange Drop Blank

Ground Symbol

Ground Tag

Jack Output Barrel Mono (With Cable Grip)

Jack Output Barrel Mono

Jack Output Barrel Stereo

Jack Output Barrel Stereo (With Cable Grip)

Jack Output Fishman Acoustic Endpin

Jack Output Mono Switched Normally Closed

Jack Output Mono Switched Normally Open (Rickenbacker)

Jack Output Mono

Jack Output Music Man 9-Pin

Jack Output Music Man Switched

Jack Output Stereo

Jack Output Takamine Acoustic

Jack Plug Mono

Jack Plug Stereo

Mod Treble Bleed (Parallel)  
Mod Treble Bleed (Series & Parallel)  
Mod Treble Bleed (Series)  
Pickup and Switch Mapping Indicators  
Pickup Danelectro Lipstick Tube  
Pickup DeArmond  
Pickup Fender Jaguar Rear  
Pickup Fender Jaguar  
Pickup Fender Jazz Bass  
Pickup Fender Jazzmaster (Rear)  
Pickup Fender Jazzmaster  
Pickup Fender Precision Bass  
Pickup Fender Strat (Angled)  
Pickup Fender Strat (Rear Angled)  
Pickup Fender Strat (Rear)  
Pickup Fender Strat  
Pickup Fender Telecaster Bridge (Rear)  
Pickup Fender Telecaster Bridge  
Pickup Fender Telecaster Neck (Rear)  
Pickup Fender Telecaster Neck  
Pickup Fender Wide Range (Rear No Wiring)  
Pickup Fender Wide Range (Rear With 2 Conductor Wiring)  
Pickup Fender Wide Range (Rear With 4-Conductor Wiring)  
Pickup Fender Wide Range  
Pickup G&L J-Style  
Pickup G&L P-Style  
Pickup G&L Single Coil  
Pickup Gretsch Filtertron  
Pickup Gretsch Hi Lo Tron  
Pickup Hofner Staple Bass  
Pickup Hofner Staple Guitar  
Pickup Humbucker (Blade)  
Pickup Humbucker (Covered Double Poles)  
Pickup Humbucker (Covered No Poles)  
Pickup Humbucker (Covered)  
Pickup Humbucker (Hex Head Poles)  
Pickup Humbucker (Rear)

Pickup Humbucker Active  
Pickup Humbucker  
Pickup Lace Alunitone  
Pickup Lace Senor (Straight)  
Pickup Lace Sensor (Angled)  
Pickup Lace Sensor Dually  
Pickup Mini Humbucker (Covered No Poles)  
Pickup Music Man Humbucker  
Pickup P90 Dog Ear  
Pickup P90 Soapbar  
Pickup P90 Staple  
Pickup PRS Humbucker (Narrow)  
Pickup PRS Humbucker  
Pickup Rickenbacker Bass (Bridge)  
Pickup Rickenbacker Bass (Neck)  
Pickup Rickenbacker Toaster  
Pickup Rickenbacker  
Pickup Single Coil (Active)  
Pickup Single Coil (Blade Angled)  
Pickup Single Coil (Blade Straight)  
Pickup Single Coil (Rear Bar Magnet Angled)  
Pickup Single Coil (Rear Bar Magnet Straight)  
Pot (Side View)  
Pot 250K Lug 1 Ground  
Pot 250K Lug 2 Ground  
Pot 250K Lug 3 Ground  
Pot 250K Stacked  
Pot 250k  
Pot 300K Lug 1 Ground  
Pot 300K Lug 2 Ground  
Pot 300K Lug 3 Ground  
Pot 300K Stacked  
Pot 300K  
Pot 500K Lug 1 Ground  
Pot 500K Lug 2 Ground  
Pot 500K Lug 3 Ground  
Pot 500K Stacked

Pot 500K  
Pot Fender S1 Switch  
Pot Lug 1 Ground  
Pot Lug 2 Ground  
Pot Lug 3 Ground  
Pot Push-Pull 250K Lug 1 Ground  
Pot Push-Pull 250K Lug 2 Ground  
Pot Push-Pull 250K Lug 3 Ground  
Pot Push-Pull 250K  
Pot Push-Pull 300K Lug 1 Ground  
Pot Push-Pull 300K Lug 2 Ground  
Pot Push-Pull 300K Lug 3 Ground  
Pot Push-Pull 300K  
Pot Push-Pull 500K Lug 1 Ground  
Pot Push-Pull 500K Lug 2 Ground  
Pot Push-Pull 500K Lug 3 Ground  
Pot Push-Pull 500K  
Pot Push-Pull Lug 1 Ground  
Pot Push-Pull Lug 2 Ground  
Pot Push-Pull Lug 3 Ground  
Pot Push-Pull  
Pot Stacked (Side View)  
Pot Stacked  
Pot Vol and Tone In Bracket (Offset Guitars)  
Pot  
Resistor 4.7K  
Resistor 100K  
Resistor 130K  
Resistor 220K  
Resistor 470K  
Resistor Blank  
Solder Blob (Large)  
Solder Blob (Small - Lug)  
Switch 5-Way Import Switch  
Switch Fender Slider 2-Position  
Switch Fender Slider 3-Position  
Switch Fender Super Switch

Switch Fender-Style 3 and 5 Way Switch ALT  
Switch Fender-Style 3 and 5-Way Switch US  
Switch Gibson 3-Pickup Toggle (Lugs Joined)  
Switch Gibson 3-Pickup Toggle (Lugs Not Joined)  
Switch Gibson 3-Way Right Angle (Lugs Joined)  
Switch Gibson 3-Way Right Angle (Lugs Not Joined)  
Switch Gibson 3-Way Toggle (Lugs Joined)  
Switch Gibson 3-Way Toggle (Lugs Not Joined)  
Switch Gibson-Switchcraft DPDT Toggle  
Switch Goldo 3-Way 4-Wafer Switch  
Switch Gretsch Standby and Tone (Lugs Joined)  
Switch Gretsch Standby and Tone (Lugs Not Joined)  
Switch Ibanez Cor-Tek Switch  
Switch Ibanez VLX54 Switch  
Switch Ibanez VLX91  
Switch Import 3-Way Toggle (Lugs Joined)  
Switch Import 3-Way Toggle (Lugs Not Joined)  
Switch Kill Switch Momentary  
Switch Mini Toggle DPDT  
Switch Mini Toggle SPDT\_2  
Switch Mini Toggle SPDT  
Switch PRS Rotary  
Switch PRS Wafer Switch  
Switch Rotary 3-Way Four Pole (4P3T)  
Switch Rotary 4-Way Four Pole Exploded (4P5T)  
Switch Rotary 5-Way Four Pole (4P5T)  
Switch Rotary 6-Way Four Pole Exploded (4P6T)  
Switch Rotary 6-Way Four Pole (4P6T)  
Switch Rotary 6-Way TWO Pole  
Switch Schaller Megaswitch  
Switch Toggle 3PDT  
Switch Toggle 4PDT  
Switch Toggle DPDT  
Switch Toggle SPDT  
Switch Toggle SPST

# INDEX OF SWITCH INDICATORS

Pickup Map Group (3-Way HH)  
Pickup Map Group (3-Way HHH)  
Pickup Map Group (3-Way HS)  
Pickup Map Group (3-Way HSH)  
Pickup Map Group (3-Way HSS)  
Pickup Map Group (3-Way SH)  
Pickup Map Group (3-Way SS)  
Pickup Map Group (3-Way SSS)  
Pickup Map Group (3-Way Toggle HH)  
Pickup Map Group (3-Way Toggle HHH)  
Pickup Map Group (3-Way Toggle HS)  
Pickup Map Group (3-Way Toggle HSH)  
Pickup Map Group (3-Way Toggle HSS)  
Pickup Map Group (3-Way Toggle SH)  
Pickup Map Group (3-Way Toggle SS)  
Pickup Map Group (3-Way Toggle SSS)  
Pickup Map Group (4-Way HHH)  
Pickup Map Group (4-Way HH)  
Pickup Map Group (4-Way HS)  
Pickup Map Group (4-Way HSH)  
Pickup Map Group (4-Way HSS)  
Pickup Map Group (4-Way SH)  
Pickup Map Group (4-Way SS)  
Pickup Map Group (4-Way SSS)  
Pickup Map Group (5-Way HH)  
Pickup Map Group (5-Way HHH)  
Pickup Map Group (5-Way HS)  
Pickup Map Group (5-Way HSH)  
Pickup Map Group (5-Way HSS)  
Pickup Map Group (5-Way SH)  
Pickup Map Group (5-Way SS)  
Pickup Map Group (5-Way SSS)  
Pickup Map Humbucker (Angled)  
Pickup Map Humbucker

Pickup Map Jaguar  
Pickup Map Jazz Bass  
Pickup Map Jazzmaster  
Pickup Map P90 Dog Ear  
Pickup Map P90 Soapbar  
Pickup Map Pair (HH)  
Pickup Map Pair (HS)  
Pickup Map Pair (Jaguar)  
Pickup Map Pair (Jazz Bass)  
Pickup Map Pair (Jazzmaster)  
Pickup Map Pair (P-J Bass)  
Pickup Map Pair (P90 Dog Ear)  
Pickup Map Pair (P90 Soapbar)  
Pickup Map Pair (SS Angled)  
Pickup Map Pair (SS T-Style)  
Pickup Map Precision Bass  
Pickup Map Single Coil Angled  
Pickup Map Single Coil  
Switch Indicator 2-Way (Blank)  
Switch Indicator 3-Way (Blank)  
Switch Indicator 4-Way (Blank)  
Switch Indicator 5-Way (Blank)  
Switch Indicator Group 2-Way (Vertical)  
Switch Indicator Group 3-Way (Vertical)  
Switch Indicator Group 3-Way  
Switch Indicator Group 4-Way  
Switch Indicator Group 5-Way  
Switch Indicator Push-Pull (Down)  
Switch Indicator Push-Pull (Up)  
Switch Indicator Rotary 3-Way  
Switch Indicator Rotary 4-Way  
Switch Indicator Rotary 5-Way  
Switch Indicator Rotary 6-Way